



BEAMZ
MADE
EAZY

152.562_152.564 V1.2

TERRASKY RAIN & GALAXY

QUICK START GUIDE

CONTROL MENU

MENU	DESCRIPTION
AXXX	DMX address 001-512
DICW/DICC	DiCw: clockwise turn DiCc: counter clockwise turn
P1XX	Motor speed, select from 00-20 to adjust speed
P2XX	Color selection, select from 1-7 for the desired color: 1 Red, 2 green, 3 Blue, 4 Red + Green 5 Green + blue, 6 Red + blue, 7 Red + Green + Blue
P3XX	Red + Green + Blue auto mode, select from 1-9 to adjust speed
P4XX	Red + Green + Blue gradient, select from 1-9 to adjust speed
P5XX	Red + Green + Blue pulse change, select from 1-9 to adjust speed
P6XX	7 Color auto mode, select from 1-9 to adjust speed
P7XX	7 Color gradient mode, select from 1-9 to adjust speed
P8XX	7 Color pulse mode, select from 1-9 to adjust speed

DMX CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	DIMMER	000-255	Total dimmer
2		000-255	Red 0-100%
3		000-255	Green 0-100%
4		000-255	Blue 0-100%
5	STROBE	000-255	Strobe speed
6	MOTOR	0	Motor stop
		001-127	Clockwise turn speed from fast to slow
		128-255	Counter clockwise turn speed from slow to fast
7	MODE	000-050	Valid for CH1-CH6
		051-100	Color selection
		101-200	Jump
		201-255	No function
8	SPEED	000-255	Speed adjustment for Jump and Gradient modes



BEAMZ

YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT

 **beamZ^{Pro}**

offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!



BEAMZLIGHTING.COM